

cerrowire® **BARREL PRO**



Tangle-Free Guarantee

Cerrowire Innovations

Tangle-Free Guarantee*

– pulling by hand, or with a prefab cutting machine

Sequential Footage

– marked on one conductor

Dual-Striped Neutrals

– extruded stripes, easy to see from all angles



Pigtail Access

– check continuity at anytime



cerrowire® **BARREL PRO**

Operating Instructions

Tangle-Free Guarantee



Scan or
*See Cerrowire.com/BarrelPro for details

*Patent Pending

Operating Instructions

The operating instructions specify the correct usage of the Cerrowire® Barrel Pro. These guidelines are unique to setting up the Tangle-Free Barrel Pro for optimum performance and safe use. Failure to follow these instructions may result in personal injury or harm and void any guarantees.

BEFORE THE PULL

STEP 1

Remove barrel lid. Locate handholds on the center tube (fig A).



Figure A

STEP 2

Pull center telescoping tube straight up until you see the horizontal orange sticker (fig B).



Figure B



Figure C

STEP 3

After pulling the center telescoping tube straight up, rotate it 90-degrees (fig C), lining up the orange positioning stickers (fig D).



Figure D




Figure E

STEP 4

Lower center telescoping tube onto support ledge, aligning the orange guide marks (fig E).

STEP 5

Set tripod legs on the barrel lip (fig F). Use the lid locking ring to secure tripod in place (fig G).



STEP 6

Untie upper wire pigtail (fig H), pushing the wire back into the barrel (fig I).



CAUTION: Stand clear of barrel when using powered take-up equipment.
WARNING: Do not stack, roll, or spin barrel.



Figure J



STEP 7

Feed the conductor wire(s) through the top of the tripod (fig J).

STEP 8

The Barrel Pro is ready for your pull (fig K).




READY TO PULL

cerrowire
BARREL PRO

Pro Tip #1

For multi-conductor barrels, tape the conductor ends together (fig L). This way, you'll always know the length of the wire remaining in the barrel (fig M).



AFTER THE PULL

STEP 1

Remove tripod from top of barrel as shown in (Fig O).



STEP 2

Rotate center telescoping tube 90 degrees and retract into barrel as shown in (Fig P).



STEP 3




Place lid on Barrel Pro and secure retaining ring until next use as shown in (Fig Q).

Pro Tip 3

WARNING:
Do not stack,
roll, or
spin barrel.

CAUTION: Stand clear of
barrel when using powered
take-up equipment.




cerrowire
BARREL PRO

HOW TO TRACK REMAINING FOOTAGE

STEP 1 The product sticker shows which conductor has the footage numbers you'll track. In this example, the white conductor with red stripes has the sequential footage marks we'll be using (fig R).

STEP 2 Find the Bottom footage number printed on the product sticker, in this example, 32,000 (fig S).

STEP 3 Write that number at the top of the Starting Footage column of the Sequential Footage sticker (fig T).



HOW TO TRACK REMAINING FOOTAGE... Continued

STEP 4 When you've finished pulling for the day, find the footage mark on the conductor. In this example we finished the day at the 29,000-foot mark (fig U).

STEP 5 32,000 minus 29,000 is 3,000 – that's how many feet of each conductor remains in the barrel (fig V).




Figure V

STEP 6 Repeating this process after every pull keeps you up to date on how much wire is left in the Barrel Pro (fig W).

Starting Footage	Remaining Footage
32000 - 29000	3000
32000 - 30100	1900
32000 - 31500	500




Figure U




Figure W